



## INSTALLING HIGHWHITE SCREENS \*SPECIAL PRECAUTIONS\*

---

- Wear gloves at all times, never touch screen with bare hands.
- Carefully remove the screen from the tube, making sure the screen does not rub against the cardboard tube.
- Never bend the tube when handling, make sure there is someone placed every meter along the tube to avoid any bending.
- Make sure there is enough clear space to unroll the screen completely without risking damage to the surface.
- CAREFULLY unroll the screen, keep tension to avoid folds and creases.

CONTACT US IF YOU REQUIRE ADDITIONAL INFORMATION **1 877 755-3795**