



## Instructions

# Cleaning your Screen Surface

Over time dust and grime will accumulate on your screen. Without proper care, dust and handprints become more difficult to remove, causing your screen to lose adequate viewing properties.

It is important to limit contaminants in the area where your screen is installed and to regularly remove any accumulation on the screen surface by following the recommendations below. Proper care will extend your screen's life and will ensure optimal screen performance.

Because screen surfaces vary, it is important that you follow the correct instructions for your screen type. Coated screens require careful attention, as they are particularly vulnerable to damage.

### NON-COATED SCREENS

These screens should be softly wiped with a damp cloth to which a small amount of soap has been added. If the screen has a light amount of dust build-up, it is best to follow the instructions for coated screens.

### COATED SCREENS



Never use water, soap, or cleaning products when attempting to clean a coated screen. Doing so can cause permanent damage.

- Only use a **dry microfiber cloth** attached to a telescopic pole
- Using moderate pressure, gently wipe the surface with an up and down motion.
- Be sure to shake off accumulated dust after each stroke.
- Change the cloth as soon as it builds up dirt.

